



BLUE LINES = 3" Overlapping Core holes drilled to depth of 4-1/2" .

BLACK LINE = Perimeter of ANCH-1 Anchor Socket.

RED LINE = Escutcheon Perimeter (Area that will be covered by the Escutcheon).